

RIA-85-U191

AD-A147916

HDL-TR-2049

July 1984

A147916
add

TECHNICAL
LIBRARY

Automated Test Equipment for the
1MT-172 Piston Actuator

by John P. Carpenter



U.S. Army Electronics Research
and Development Command

Harry Diamond Laboratories

Adelphi, MD 20783

The findings in this report are not to be construed as an official Department of the Army position unless so designated by other authorized documents.

Citation of manufacturers' or trade names does not constitute an official indorsement or approval of the use thereof.

Destroy this report when it is no longer needed. Do not return it to the originator.

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM
1. REPORT NUMBER HDL-TR-2049	2. GOVT ACCESSION NO.	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) Automated Test Equipment for the 1MT-172 Piston Actuator		5. TYPE OF REPORT & PERIOD COVERED Technical Report
		6. PERFORMING ORG. REPORT NUMBER
7. AUTHOR(s) John P. Carpenter		8. CONTRACT OR GRANT NUMBER(s) PRON: A13EK4210101A9
9. PERFORMING ORGANIZATION NAME AND ADDRESS Harry Diamond Laboratories 2800 Powder Mill Road Adelphi, MD 20783		10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS Program Ele: 64623A DA Proj: 1M4646230068
11. CONTROLLING OFFICE NAME AND ADDRESS Army Materials and Mechanics Research Center Watertown, MA 02172		12. REPORT DATE July 1984
		13. NUMBER OF PAGES 41
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office)		15. SECURITY CLASS. (of this report) UNCLASSIFIED
		15a. DECLASSIFICATION/DOWNGRADING SCHEDULE
16. DISTRIBUTION STATEMENT (of this Report) Approved for public release; distribution unlimited.		
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)		
18. SUPPLEMENTARY NOTES HDL Proj: 400042 DRCMS code: 6446230680012		
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) Piston actuator Automation Force Test Displacement		
20. ABSTRACT (Continue on reverse side if necessary and identify by block number) An automated tester for the 1MT-172 piston actuator has been developed. The actuator is an electroexplosive device that, when electrically initiated, extends a piston. This actuator is used in several safety and arming devices developed by the Army. The project, funded by Manufacturing Testing Technology (MTT) funds, was sponsored by the Army Materials and Mechanics Research Center (AM-MRC). The output of the automated tester is the piston-force-versus-stroke-displacement curve for the actuator. This tester also makes GO/NO-GO decisions based on peak force values and computes the total energy output. A hard-copy record is available from a self-contained plotter.		

CONTENTS

	<u>Page</u>
SUMMARY	5
1. INTRODUCTION	7
2. TESTER DEVELOPMENT	10
3. CONCLUSIONS	16
4. RECOMMENDATIONS	16
DISTRIBUTION	41
APPENDIX A.--ACCELEROMETER CHARACTERISTICS	17
APPENDIX B.--SMARTSCOPE LITERATURE	21
APPENDIX C.--PAT PROGRAM LISTING	27
APPENDIX D.--PAT OPERATOR'S MANUAL	35

FIGURES

1. Electroexplosive piston actuator	7
2. Piston actuator tester block diagram	8
3. NAVSWC/WO instrumentation for piston actuator tests	9
4. Function test instrumentation	9
5. Pendulum arm	10
6. Test fixture	12
7. Sample hard-copy output	14
8. Six-pole active low-pass filter	14
9. Torque versus rotation, PAT return spring	15

SUMMARY

An automated tester for the 1MT-172 piston actuator has been developed. The actuator is an electroexplosive device that, when electrically initiated, extends a piston. This actuator is used in several safety and arming devices developed by the Army. The project was funded by Manufacturing Testing Technology funds and sponsored by the Army Materials and Mechanics Research Center. The output of the automated tester is the piston-force-versus-displacement curve for the actuator. This tester also makes accept/reject decisions based on peak force values and computes the total energy output. A hard-copy record is available from a self-contained plotter.

As a result of this project, actuator samples can now be evaluated more rapidly and more accurately than previously possible. Screening of production samples can be made with a much higher degree of precision and confidence. This screening will yield a decreased risk of fuze failures due to poor actuator performance and thus provide potential savings of many times the project's cost. In addition, the new test technique yields design and performance information, not otherwise obtainable, of significant value to the development effort or new fuze systems.

1. INTRODUCTION

Harry Diamond Laboratories (HDL) was funded by the Army Materials and Mechanics Research Center (AMMRC) to develop a testing device for the 1MT-172 piston actuator. This actuator is used in the SEAGNAT fuze, the Multiple Launch Rocket System (MLRS) fuze, and the shoulder-launched multipurpose assault weapon (SMAW) fuze, all developed by HDL. The amount of funding was \$85,000. The piston actuator is a small (0.62 in.* long x 0.135 in. diam) electroexplosive device that rapidly extends a piston when approximately 5 mg of propellant is initiated by sufficient electrical energy (see fig. 1). The tester was to safely initiate the actuator, measure the piston's acceleration, and then compute and plot the output force versus the displacement of the piston. Peak force, pulse duration, and total energy developed were also to be recorded.

The tester was to be a stand-alone automated device requiring only low operator skill. Operator safety and near real-time analysis were also design requirements. The general components of the device were to be a fixture for holding the actuator, an accelerometer and signal conditioners for obtaining the acceleration pulse, and a microprocessor for computing and plotting the output information. The development was to result in a piece of test equipment that could be used in a production environment to run first article and lot acceptance tests (see fig. 2).




Figure 1. Electroexplosive piston actuator.

Force: 40 lb min (est.)
Extension: 0.17 in.
Dimensions in inches

*in.(2.54) = cm.




Figure 2. Piston actuator tester block diagram.

The project was considered a low development risk because HDL had previously obtained similar data in a laboratory environment. In that effort, piston actuators were used to fire accelerometers into the air. The pulses were recorded on magnetic tape and sent out of HDL for analysis plotting (see fig. 3). Plots were obtained for acceleration versus time directly, and for velocity and displacement versus time by integration of the acceleration curve. Since the mass of the accelerometer was known, the acceleration plot could be scaled to obtain force versus time. The force-versus-time and displacement-versus-time plots were hand digitized at simultaneous time points to obtain a plot of force versus displacement. The new tester was to perform the same operations but essentially in real-time operation.

The prior method of testing piston actuators is outdated and misleading. The actuators are tested by initiating the actuator, letting the piston cross a gap, and then recording the impact force the piston exerts against a load cell (see fig. 4). This may be a good test of the piston actuator's ability to excite an impact transducer, but piston actuators are not used in an impact mode in HDL fuzes. Typically, the piston actuator is used to remove a mechanical lock on an explosive train interrupter. The locks are usually staked in place and must be moved out of the way, using a high initial force to break the stake. Low-level continuing force is needed to move the lock. The force-versus-displacement data computed by the new tester show the shape of the force output curve whereas the old method only shows the total energy output. An actuator that has a low peak force but a high continuing force may

be inadequate for breaking the stake on a mechanical lock; however, when tested with the old equipment, it appears the same as an adequate actuator.




Figure 3. NAVSWC/WO instrumentation for piston actuator tests (May 1979).




Figure 4. Function test instrumentation.

2. TESTER DEVELOPMENT

The test device had to be able to compute or sense directly the force output of the piston actuator. This could be performed by using a load cell for direct sensing or by using an accelerometer and computing the force by scaling the pulse. Since the load cell proved difficult to mount and the acceleration pulse can be integrated to obtain velocity and displacement data, an accelerometer was used. The load cell pulse could be scaled also. The previous investigation used an Endevco 2262-2000 piezoresistive viscous damped accelerometer. This accelerometer was obsolete when the new development began. A similar device, the Endevco 2262C-2000, half as sensitive, was available and was purchased. Laboratory tests on this device showed that the replacement accelerometer was not sensitive enough for this application. Endevco piezoelectric accelerometers were considered as a replacement. These accelerometers require a charge amplifier and are sensitive to cable whip between the accelerometer and the charge amplifier. PCB Piezotronics, Inc. makes a piezoelectric accelerometer, the 305A04, that has a self-contained charge amplifier. There is no problem with cable whip, and the device had the proper sensitivity. This accelerometer was purchased and used as a replacement for the Endevco 2262-2000 (see app A).

The output of the piston actuator was used to accelerate the acceleration transducer. To prevent damage, the transducer must be restrained. Both linear and rotational restraint methods were considered. A linear system simplifies the modeling of the device and its calibration. Such a system might consist of an actuator holder, the accelerometer transducer, and a tube to guide and catch the accelerated transducer. The disadvantage of the linear method is that the cable must travel along the path of the accelerometer. This causes the cable to flex and might lead to early failure. A rotational system is more difficult to model and calibrate but the cable can be better protected. This system would consist of an accelerometer mounted on the end of a pendulum arm. The piston actuator would be used to swing the pendulum arm. In this system the cable can be tied to the arm and does not flex. Thus, the rotational system was chosen for the tester (see fig. 5).

The PCB accelerometer is not a mechanically damped transducer. Signal conditioning was necessary to eliminate ringing in the accelerometer pulse. Laboratory instrumentation filters were used until the proper filter characteristics were determined. A custom filter was then built to match these characteristics.

Figure 5. Pendulum arm.



The force-versus-displacement curve was to be computed from the acceleration-versus-time curve and its second integral, the displacement-versus-time curve. The signal processing equipment was to be able to digitize the filtered accelerometer pulse, integrate and scale the curves, find parameter values such as peak force, and provide a hard-copy record. Several pieces of microprocessor-based equipment were evaluated. The Tektronix 8664 oscilloscope could do all the required operations but provided no hard copy. A microprocessor and plotter had to be added to obtain hard copy. This addition required interfacing the components with two microprocessors, one in the scope and one in the controller. The next system evaluated was a Nicolet Explorer III oscilloscope tied to a controller and plotter. This was simpler than the Tektronix and it permits statistical analysis of the data, but it still required custom interfacing of the components. T. G. Branden, Inc. offered a measurement system, "Smartscope," that required no interfacing and came complete with all the necessary system software. The system consisted of a controller/digitizer, a video monitor, a disk drive, and a plotter. All system functions were programmable and the equipment was low cost. This measurement system was purchased (see app B).

Integration of the test system concerned itself with three areas: system input, system output, and the interface between the operator and the system. Input data consisted of the acceleration pulse, calibration data, scope setup, tester programming, and reference values for attribute testing. The acceleration pulse came through the signal conditioning filter, and the calibration method was determined at the end of the tester development effort. Scope setup and tester programming was set up to occur automatically when the tester power was turned on (see app C). The reference values for attributes are contained in the software and are not normally accessible to the operator. These values can be changed, when the tester program is loaded, by anyone who knows the program protect code.

System output includes the hard-copy, force-versus-displacement plot, parameter values recorded on the hard-copy plot, a video display of the hard-copy material, and the video display of attribute tests. Data display is automatic and requires no operator action.

The operator would be required to perform a minimum of actions. Ideally, only loading the actuator and initiating the test sequence by the press of a button would be necessary (see app D).

The piston actuator test (PAT) system is physically composed of a fixture, a firing circuit console, the PCB accelerometer, an instrumentation filter, and the T. G. Branden Smartscope. The fixture has three main components: the support and pendulum arm assembly which holds the accelerometer, the piston actuator holder, and the enclosure. The enclosure, made of 5/8-in. plexiglass, protects the operator and observers from the piston actuators (see fig. 6).






Figure 6. Test fixture: (a) front view, (b) side view, (c) back view.

To start and operate the system, the operator loads the tester floppy disk into the disk drive. Power is turned on. The tester program and scope setup are loaded automatically by Smartscope's microprocessor. The operator then ensures that the firing circuit is set to the safe position and loads the piston actuator into the fixture. The operator then pushes the "RUN" button on the scope controller. The video monitor notifies the operator when to fire the actuator. The actuator is fired by setting the firing circuit to the armed position and pushing the fire button. The only remaining task for the operator is to load paper into the plotter if a hard copy record is desired. The microprocessor takes the acceleration pulse and scales it to obtain "g's." It then integrates this signal to obtain the velocity-versus-time curve. The velocity curve is used to compute the total energy parameter. The velocity curve is then integrated to obtain the displacement-versus-time curve. At this point the processor recalls the "g"-versus-time curve and scales this curve to get the force-versus-time curve. The computer determines the maximum and minimum force values. The maximum force is checked against a reference value. If the value is inadequate a message appears on the video to that effect. The amplitudes of the force versus time and the displacement versus time are plotted against each other. This gives the force-versus-displacement plot required by the system specification. A hard-copy record of the plot, the maximum and minimum force, and the total energy are available by selecting "PLOT" from the scope controller (see fig. 7).

The system required optimization of the the custom filter, the pendulum arm, and the accelerometer mount. Several design iterations were required on all three items before satisfactory results were obtained. The final filter schematic is shown in figure 8.

The system was calibrated by using an energy method. The pendulum arm has a wind-up spring device that stores the energy imparted to it by the actuator. The potential energy stored in the arm by a pulse can be compared to the kinetic energy that the pulse gives to the arm. This comparison determines the effective inertia of the system. The inertia value is used to scale acceleration measurements to get force values. An initial inertia value was assumed and then modified to fit the experimental data.

The inertia was assumed to be $I = mr^2$, where m is the mass of the accelerometer at the end of the pendulum plus one-third the mass of the pendulum rod, and r is the radius at which the accelerometer is mounted. This mass was 37.56 g. The radius is 9 in. The resulting inertia estimate is $I_e = 0.01736 \text{ lb-s}^2\text{-in}$. The energy represented by spring wind-up is given by $E_p = T\theta$, where E_p is the potential energy stored, T is the torque applied, and θ is the rotation of the pendulum in radians if torque is constant. The pendulum spring used is a constant torque-negator-type spring, and the torque is very nearly constant in the θ range used (see fig. 9). The pendulum is mounted on ball bearings, so friction loss is minimized. The energy put into the system for the calibration was equal to 11.46 in.-lb. The potential energy stored by the spring should be equal to the kinetic energy that the arm has prior to spring wind up. This energy is given by $E_k = (1/2)Iw^2$, where E_k is the kinetic energy, I is the inertia, and w is the rotational velocity of the pendulum arm; w is equal to XD/r where XD is the tangential velocity of the

FORCE VS DSPL





Figure 7. Sample hard-copy output.



Notes:

1. Connect pin 4 of HA4741 to +10 V.
Connect pin 11 of HA4741 to -10 V.
2. FMB 10 kHz.

Figure 8. Six-pole active low-pass filter.




Figure 9. Torque versus rotation, PAT return spring.

pendulum arm. A calibrated accelerometer is used to obtain the change in this velocity over the stroke of the piston actuator. Since the initial velocity was zero, the final velocity is determined. This value was 297.22 in./s. If the estimated value for the inertia is correct, the potential and kinetic energy should be equal:

$$E_p = 11.46 \text{ in.-lb}$$

$$E_k = \frac{1}{2} I \omega^2$$

$$= \frac{1}{2} I (X D / r)^2$$

$$= 0.5(0.01736) (297.22/9)^2$$

$$= 9.47 \text{ in.-lb.}$$

The ratio between the two energies is 11.46/9.47 or 1.21. This represents the error in the estimated inertia. The actual effective inertia can be computed using the following ratio: $I_{\text{actual}} = 0.01736 (1.21) = 0.02101 \text{ lb-s}^2\text{-in.}$ Once the inertia has been determined the force for any value of acceleration can be calculated from the equation,

$$\begin{aligned} T &= I ODD \text{ and } ODD = XDD/r, \\ F r &= I XDD/r, \\ F &= I XDD/r, \text{ and} \\ F &= 0.0002594 XDD, \end{aligned}$$

where XDD is the tangential acceleration and ODD is the angular acceleration. This is the equation used to calculate the force-versus-time curve from the acceleration-versus-time curve in the piston actuator tester program.

The tester reliability and consistency were demonstrated by running a test of 100 actuators. No system problems were discovered in these tests. The

tester has also been used as part of a first article test for piston actuators on SMAW's. The MLRS has used the tester to qualify a new piston actuator design. HDL is trying to develop alternative sources of supply for the actuators. The tester has been used to compare actuators from different manufacturers as part of this effort.

3. CONCLUSIONS

The piston actuator tester developed by HDL meets the design requirements established by the MTT program. A force-versus-displacement plot and parameter values are available on a video or hard-copy record. The video display is available 30 s after actuator initiation. This is a short enough time span to allow production testing of actuators. The tester makes GO/NO-GO decisions based on the parameter values. Operator skill required is low and the tester is self-contained.

4. RECOMMENDATIONS

Purchase specifications for piston actuators should be changed to include sample testing by testers of this type.

APPENDIX A.-- ACCELEROMETER CHARACTERISTICS

(Courtesy of PCB Piezotronics, Inc.)

LOW-IMPEDANCE, VOLTAGE-MODE
HIGH-SHOCK ACCELEROMETER
 with built-in amplifier
Series 305A

PCB
 PIEZOTRONICS

MOTION
 shock & vibration

- rugged, light-weight, highly reliable design
- very high resonant frequency
- built-in amplifier – low impedance output
- no zero shift
- operates over long coaxial or 2-wire cables
- quality signal independent of cable motion or length


For measurement of high amplitude pyrotechnic shocks associated with ballistic projectiles, metal to metal impacting, explosive forming, closed bombs and blast effects on structures.

Model 305A quartz accelerometer measures mechanical shock motion to 100 000 g. Small size and light weight impart fast response (less than 10 microseconds) and assure a minimum effect on the structure of the test object. It follows transient events up to 0.1 second duration and generates a quality signal independent of cable length, condition and motion.

This miniature transducer with an integral mounting stud installs by threading into a tapped hole in the structure of the test object. For electrical connections in extreme shock environments, the optional solder pin connector adaptor and fine stranded ribbon wire (007A Cable Assembly) has proved more durable than coaxial components.

The rigid structure of this transducer contains a very small seismic mass preloaded against a quartz element by a thin walled sleeve, mechanically isolated from the outer case. A built-in unity-gain microelectronic amplifier lowers the output impedance and improves resolution by eliminating the cable capacitance effect on amplifier noise.

When connected to a PCB power unit, self-amplifying PCB transducers generate a high-level, low-impedance analog output signal proportional to the measurand and compatible with most readout instruments. Power is supplied over the signal lead.



SPECIFICATIONS: Model No.

Model No.	305A
Range, FS (5V output)	g 100 000 ⁽¹⁾
Resolution	g 2.0
Sensitivity	mV/g 0.05
Resonant Frequency (mounted)	Hz 60 000
Time Rise	μs 5
Discharge Time Constant	s 2
Frequency Response (±5%)	Hz 0.25 to 8000
Frequency Response (2.5dB)	Hz 0.15 to 20 000
Linearity	% 1
Overload Recovery	μs 10
Output Impedance	ohm <100
Transverse Sensitivity	% 5
Strain Sensitivity	g/μin/in 0.2
Temperature Coefficient	%/°F 0.03
Temperature Range	°F -100 to +250
Vibration/Shock (max transverse)	g 75 000/30 000
Weight	gm 4.5
Excitation/Constant Current	VDC/mA -18 to +28/2 to 20

(1) Optional 5V Ranges

50 000 g	0.1 mV/g
10 000 g	0.5 mV/g
5000 g	1 mV/g
2500 g	2 mV/g
Charge-Mode	0.2 pC/g


Model No.

305A02
305A03
305A04
305A05
315B ⁽²⁾


(2) Larger Size (.47 Dia x .70 High)

To specify metric Thd M5 x 0.8, add prefix "M" to model no – e.g. M305A

TYPICAL RESULTS



TYPICAL SYSTEM:



APPENDIX B.--SMARTSCOPE LITERATURE

(Excerpted from "SMARTSCOPE, Bringing Intelligence to Waveform
Analysis," T. G. Branden Corporation, 1979)

The Hardware

very digital Processing Oscilloscope in the Smartscope series is a complete system for the acquisition, display, and processing of analog signals in the time domain. Designed around a 16 bit microprocessor and two or four 12 bit A to D converters, Smartscoopes combine hardware with powerful software routines specifically designed



to handle waveforms. Whether your results are to be displayed and analyzed on screen, stored on disc, plotted or transmitted to a computer, Smartscoopes are a cost-effective way.

Waveforms are displayed on a 9" (diag.) screen easily viewed even in brightly lit environments. "Loop through" video allows additional displays to be added as required.

Programmable to us means that all hardware except the power switch can be controlled by the software. All machine functions such as input sensitivity, sweep time, and trigger conditions are selected through a calculator style keypad. This same keypad is used for the manipulation and storage of acquired data.

An optional RS-232C input/output port provides for the transfer of waveform data, registers, machine set-up, messages, and programs. Transfer can occur from a Smartscope, computer, or terminal to a Smartscope, computer, or terminal. All transfers are in standard ASCII form.

An IEEE-488 option meets all requirements of the 1978 standard for a listener and talker. The same data transfer functions of RS-232C are provided with this option.

Hard copy of acquired waveforms, display annotations, and measurement read-outs is provided by a digital plotter. A fully annotated dual channel display takes no more than 3 minutes to plot. Plots are made on standard 8½ x 11" paper with pen and ink so no special paper is required.

Depending on the model chosen, 2 or 4 channels of data are acquired. The incoming analog data is converted to digital data simultaneously in all channels. This means no multiplexing of channel inputs and effectively no time skew between channels.



An external trigger input is provided as well as an internal connection to CH 1 only.

A continuously variable sweep delay allows display of times before and after the trigger event.

- Up to 66 KHZ sample rate (15 us per point)
- 2 to 8 arrays for channel storage
- Up to 4 arrays displayed
- Variable memory length per channel (up to 10,000 data points single channel)
- Four acquisition modes — manual, transient, repeated and an autorange that automatically seeks a correct amplitude range for each channel.
- Input sensitivity from ± 100 mv to ± 20 volts
- Choice of AC or DC coupling
- X10 probe selection automatically adjusts readout
- User selected Engineering units for calibration of both time and amplitude.
- Number of arrays and channels dependent on model selected.

Make your transient recorder or sampling scope smarter. In most cases, the analog output from a transient recorder or sampling oscilloscope can be transferred to the Smartscope. All the processing and data handling power becomes available even though the



signal occurred too fast for the Smartscope to acquire directly. Our basic system price begins to make this a cost effective alternative. Contact us for more details and a specific recommendation for your equipment or application.

The Software

Dual cursors, whose positions are independently controlled from the keypad can be moved to any point on a display. Digital readout of amplitude and time values are displayed and updated on screen each time a cursor location is changed. Cursor motion can be selected to move point to point, to seek a local maximum, to seek a local minimum, to go to a specified time location, or to seek a specified amplitude value.


Array and register operators bring up powerful routines to process and manipulate waveforms and registers.

- Definite Operators — Operate on data between cursor settings resulting in a numeric value for Peak-Peak, RMS, Slope, Definite Integral, Area under the Curve, 1/Delta Time, Rise-Time and Mean.
- Array Operators — Operates on entire array to Differentiate, Integrate, Smooth, Data Shift and Data Rotate.
- Math Operators — Applies operators to make numeric modifications to arrays or registers or to apply a set of Transcendental operators (sine, cosine, arctangent, log, ln, square root or exponential) to arrays or registers.
- Inverse Definite Operators — The Inverse Definite Operator for Peak to Peak positions the cursors to the max and min points on a waveform.

Set up and review of machine conditions are accomplished from a single screen. The review screen displays the current settings of input sensitivities and coupling, sweep time and delay settings as well as trigger conditions. Using the keypad, a blinking cursor may be positioned to any of these conditions and a change made by use of editing keys.

A glance at the review screen gives a complete, easy to understand picture of machine state without having to interpret knob or variable control settings. A review screen for a two channel unit with fixed array length per channel is shown on the right.


Up to 8 arrays are available for storage and manipulation of acquired data. In some models, array length can be selected for up to a total of 10,000 data points.



- A choice of display formats allows up to four arrays to be displayed on screen at a time. Combinations are:
- Array amplitude vs. time (up to 4 arrays).
 - Up to 4 arrays vs. another array.
 - Superposition of arrays on a common base line.
 - Expansion of a portion of the arrays horizontally and vertically.

Displays may be fully annotated to represent the actual parameters you are working with. The horizontal or vertical axes may be labeled for clarity and the readout register label and units may be set to represent your measurement units. Date, title, and time of acquisition may be displayed to further document the measurement made. The digital plotter option will provide you a hard copy of what's on screen suitable for reports, engineering notebooks, test or quality assurance records. And the information may also be stored on floppy disc for later display or plot.

A keypad programming option allows you to create your own measurement programs in a manner similar to a programmable calculator. You select a learn mode and perform your measurement as you normally would. The Smartscope will remember the keystrokes you made, and perform that sequence each time the run button is pressed. Additional keys allow you to list your program, edit it, insert steps, delete steps, or store the





program on disc for later recall. Conditional branching, screen control, and choice of learn time or run time data entry are also available in addition to the normal operation of the machine. Whether your need is repetitive measurements, go-no-go testing, hard copy generation, disc storage, screen messages or data exchange through a RS-232C or GPIB port, all these operations and more can be done under program control.

A Model 700 Disc optional addition to the Smartscope provides storage and retrieval of: waveform data, machine set-up conditions and user applications programs. Storage space is dynamically allocated on the disc and files are addressed and listed on a directory by user created names. The directory shows the space remaining on a diskette for storage. Software file protect and error checking routines for soft and hard errors are built in. An additional option is available to allow a machine setup file to be automatically loaded from the disc on power-up. This is especially useful in a production environment. The media is commonly available 5¼" diskettes.

The Model 730 Digital Plotter option provides fully annotated hard copy of Smartscope displays. The plotter uses pen and ink to plot on standard 8½ x 11" paper. All required software is provided with this option. A reduced size reproduction of a Model 730 plot is shown on the right.

© 1979 T. G. BRANDEN CORPORATION. ALL RIGHTS RESERVED.



APPENDIX C.--PAT PROGRAM LISTING

PAT Program LISTING

1. IDENTIFY	5. MOV
4. REGISTER LABELS, UNITS	1. MEMORY CHAN
REGISTER 3-00	MEMORY CHANNEL 3
REGISTER LABEL: VEL	
REGISTER UNITS: MPS	6. MATH OPERATORS
4. REGISTER LABELS, UNITS	3. CONSTANT
REGISTER: 3-01	CONSTANT: 0
REGISTER LABEL: VEL	5. MOV
REGISTER UNITS: MPS	1. MEMORY CHAN
	MEMORY CHANNEL 1
	7. MATH OPERATORS
	3. CONSTANT
	CONSTANT: 0
EXIT	
2. IDENTIFY	5. MOV
4. REGISTER LABELS, UNITS	1. MEMORY CHAN
REGISTER: 3-13	MEMORY CHANNEL 4
REGISTER LABEL: TIME	
REGISTER UNITS: MS	8. MESSAGE
4. REGISTER LABELS, UNITS	
REGISTER: 3-14	PLEASE WAIT 5 SECONDS AND
REGISTER LABEL: TIME	
	FIRE THE PISTON ACTUATOR
	9. ACQUIRE
REGISTER UNITS: MS	
EXIT	10. DISPLAY
3. MESSAGE	1. TIME
PISTON ACTUATOR TESTER	MEMORY CHANNEL 1
	MEMORY CHANNEL 3
4. PAUSE	MEMORY CHANNEL 4
1. TIMED PAUSE	EXIT
PAUSE LENGTH IN SECONDS	
5. MATH OPERATORS	11. MAIN SCREEN ON/OFF
3. CONSTANT	1. ON
CONSTANT	

APPENDIX C

12. MATH OPERATORS

- 1. MEMORY CHAN
MEMORY CHANNEL 1
- 5. MOV
MEMORY CHANNEL 3

13. MATH OPERATORS

- 3. CONSTANT
CONSTANT: 970.87
- 3. MPY
- 1. MEMORY CHAN
MEMORY CHANNEL 3
MEMORY CHANNEL 3

14. MEMORY CHANNEL OPERATORS

- 2. INDEFINITE INTEGRAL
MEMORY CHANNEL 3

15. MATH OPERATORS

- 3. CONSTANT
CONSTANT: 386.4
- 3. MPV
- 1. MEMORY CHAN
MEMORY CHANNEL 3
MEMORY CHANNEL 3

16. MATH OPERATORS

- 1. MEMORY CHAN
MEMORY CHANNEL 3
- 5. MOV
MEMORY CHANNEL 4

17. MEMORY CHANNEL OPERATORS

- 2. INDEFINITE INTEGRAL
MEMORY CHANNEL 4

18. PAUSE

- 1. TIMED PAUSE
PAUSE LENGTH IN SECONDS

19. MAIN SCREEN ON/OFF

- 2. OFF

20. IDENTIFY

- 4. REGISTER LABELS, UNITS
REGISTER: 1-00
REGISTER LABEL: FORC
REGISTER UNITS: LBS
- 4. REGISTER LABELS, UNITS
REGISTER: 1-01

REGISTER LABELS: FORC

REGISTER UNITS: LBS

EXIT

21. MATH OPERATORS

- 3. CONSTANT
CONSTANT: 98.79
- 3. MPY
- 1. MEMORY CHAN
MEMORY CHANNEL 1
MEMORY CHANNEL 1

22. IDENTIFY

- 3. MEMORY CHANNEL LABELS
MEMORY CHANNEL 1
VERTICAL LABEL: FORCE
HORIZONTAL LABEL: TIME
- 3. MEMORY CHANNEL LABELS
MEMORY CHANNEL 4
VERTICAL LABEL: DSPL
HORIZONTAL LABEL: TIME
- 5. TITLE

DISPLAY TITLE: FORCE VS
EXIT

23. IDENTIFY

- 4. REGISTER LABELS, UNITS
REGISTER: 4-00
REGISTER LABEL: DISP
REGISTER UNITS: UIN
- 4. REGISTER LABELS, UNITS
REGISTER: 4-01

REGISTER LABEL: DISP
REGISTER UNITS: UIN
EXIT

24. DISPLAY

- 2. MEMORY CHAN
MEMORY CHANNEL 4
MEMORY CHANNEL 1

EXIT

25. CURSOR RESET

26. INVERSE DEFINITE OPERATORS
MEMORY CHANNEL 1

27. CONDITIONAL

- 2. REGISTER
REGISTER NAME 1-00
- 5. GREATER THAN
- 1. CONSTANT
CONSTANT 100
LABEL AAA

28. CLEAR SCREEN

29. MESSAGE

NOT ENOUGH POP TO IT

30. PAUSE

- 1. TIMED PAUSE
PAUSE LENGTH IN SECONDS

31. AAA:

32. CURSOR RESET

33. HORIZ EXPAN

34. CURSOR RESET

35. INVERSE DEFINITE OPERATOR
MEMORY CHANNEL 1

36. MATH OPERATORS

- 3. CONSTANT
CONSTANT: .000083333
- 3. MPY
- 3. REGISTER
SECOND SOURCE REGISTER

DESTINATION REGISTER: 00

37. MATH OPERATORS

- 2. REGISTER
REGISTER: 00
- 3. MPY
- 2. REGISTER
SECOND SOURCE REGISTER:

DESTINATION REGISTER: 00

APPENDIX C

```
38. MATH OPERATORS
    3. CONSTANT
        CONSTANT: .0015806
    3. MPY
    2. REGISTER
        SECOND SOURCE REGISTER:

        DESTINATION REGISTER: 00

    POSITION 1: -
    POSITION 2: -
    POSITION 3: -
    POSITION 4: -
    POSITION 5: - 8-01
    POSITION 6: -
    POSITION 7: EXIT

39. MATH OPERATORS
    3. CONSTANT
        CONSTANT: 0

    3. MPY
    1. MEMORY CHAN
        MEMORY CHANNEL 8
        MEMORY CHANNEL 8

40. MATH OPERATORS
    3. CONSTANT
        CONSTANT: EXIT

41. MATH OPERATORS
    2. REGISTER
        REGISTER: 00
    1. ADD

    MEMORY CHAN
    1. MEMORY CHAN
        MEMORY CHANNEL 8
        MEMORY CHANNEL 8

42. IDENTIFY
    4. REGISTER LABELS, UNITS
        REGISTER: 8-01
        REGISTER LABEL: ENGY
        REGISTER UNITS: FLB
    7. SELECTED REGISTERS

43. PROGRAM END
```

SCOPE SET-UP PARAMETERS

	RANGE	INPUT	PROBE	OFFSET	FACTOR
CH1	10.V	AC	#1	0	850.0E-
CH2	5.0V	AC	#1	0	1.000

ACQUISITION MODE	TRANSIENT
TOTAL SWEEP TIME IN SECONDS	2.000E-3
POST TRIGGER DISPLAY IN SECONDS	1.800E-3
TIME FACTOR	1.000E+3
OFFSET	0

	SOURCE	SLOPE	PERCENT
TRIGGER	CH1	+	10

NUMBER OF MEMORY CHANNELS	8
SIZE OF MEMORY CHANNELS	200

APPENDIX D.--PAT OPERATOR'S MANUAL

D-1. OPERATING SEQUENCE

This procedure covers the operating sequence for the piston actuator tester (PAT). It consists of a step-by-step procedure, a list of operator-correctable problems and cures, and the scope setup values.

D-1.1. Startup Operation

The tester programming and oscilloscope setup values are stored on an 8-in. floppy program disk. This disk must be inserted into the disk drive before power is applied to the oscilloscope body. First, turn on the power to the plotter, the video monitor, and the disk drive. Insert the program disk into the drive. The disk is inserted with the label on top and the oval cutout toward the disk drive. Next, turn on the power to the scope mainframe. The program and scope setup values will be loaded automatically. When the red light on the disk drive goes out, the program has been loaded. The video display will show the scope name and manufacturer. Next, turn power to the firing circuit and the transducer ON. The transducer needle display should be in the green area. Firing circuit voltage is operator-selectable, but is usually 25 V. Make sure the firing circuit controls are OFF and the arming switch is in the SAFE position. The tester is now ready for loading.

D-1.2. Loading the Piston Actuator

Follow local safety procedures for handling electroexplosive devices. Insert a piston actuator into the copper body clip. Put the assembly into the actuator cylinder. The cylinder should then be loaded into the holding fixture located at the base of the pendulum support. An overcenter clamp is used to secure the cylinder in place. Release the pendulum ratchet and set the pendulum arm against the piston actuator. Close and secure the enclosure door. Switch the arming switch to the ARMED position and check the resistance of the actuator. This resistance reading can be obtained from the two yellow terminals on the firing panel. The device must be checked with a low-current ohm meter. Do not apply more than 2 mA to the piston actuator through the yellow terminals. Switch the arming switch to the SAFE position. Turn the firing circuit ON. Set the arming switch to the ARMED position. The piston actuator is now ready to fire.

D-1.3. Running a Test Sequence

The scope mainframe has a control board attached to it by a length of flex cable. In the lower right-hand side of the board is a button marked R/S. When the button is pushed, the test sequence begins. The video display will ask the operator to fire the piston actuator. This is done by pressing the red firing button on the firing circuit panel. The tester will then display a number of curves. If the force output of the actuator is too low, the video display will have a message to that effect. After a short period the words PROGRAM END will be displayed and the force versus displacement curve will be shown. The operator should then turn the firing circuit off and set the arming switch to the SAFE position.

D-1.4 Hard-Copy Records

The program for plotting the video display is not automatically loaded into the computer. It must be manually loaded by the operator. The loading is done via the scope mainframe control board. The loading operation does not erase the video display or the tester program. The sequence used to load the plot program is shown below: Lower-case notations represent responses made by the computer on the video screen. Upper-case and numerical notations represent the operator's input. The input consists of pushing the scope control-board button indicated:

Op--DISK

Cm--menu (the computer lists a menu of selections)

Op--No. 8 (options)

Cm--menu (which option?)

Op--No. 2 (plotter)

Cm--menu (load or save?)

Op--No. 1 (load)

Cm--no change--the computer is loading the plot program. When the loading operation is finished the video display will be returned and plots can be made.

The plot is obtained by pushing the button on the scope control board marked PLOT. The computer will ask the operator to input the number 1 if the plotter pen is in the lower left-hand position. When the number is entered, the plot is started. At the end of the plotting sequence, the video display is returned. Once the plot routine has been loaded it will stay in the microprocessor memory until the power is turned off.

D-2. TROUBLE SHOOTING

Problem	Fix
1. Program stops in mid-execution	Press R/S button--program may continue. If not, press reset on scope. Data will be lost but program may reset. Last resort is to switch scope body off and then on again. Program will autoloading and you can begin again.
2. Program does not respond to firing of piston actuator	Sensitivity is too low. Press SETUP button and change the voltage scale for channel one to a lower value.
3. Plotter action erratic	Reload plot program. Data are not lost during this process.

4. Scope does not autoloading program correctly

Shut off power and restart tester. If this fails the disk may be bad. Use spare disk.

5. Scope traces are off scale

Sensitivity may be too high. Correct as in No. 2. Accelerometer cables or accelerometer may be loose. Tighten them.

6. Miscellaneous

The last resort of any fix is to shut off the power and restart the tester.

DISTRIBUTION

ADMINISTRATOR
DEFENSE TECHNICAL INFORMATION CENTER
ATTN DTIC-DDA (12 COPIES)
CAMERON STATION, BUILDING 5
ALEXANDRIA, VA 22314

COMMANDER
US ARMY MATERIALS & MECHANICS
RESEARCH CENTER
ATTN DRXMR-PL, TECHNICAL LIBRARY
ATTN DRXMR-STQ, F. STENTON
ATTN DRXMR-STQ, P. W. ROLSTON
ATTN DRXMR-T, MECHANICS & ENGINEERING
LABORATORY
ATTN DRXMR-M, MATERIALS TESTING
TECHNOLOGY DIV
ATTN DRXMR-R, ORGANIC MATERIALS LABORATORY
ATTN DRXMR-E, METALS & CERAMICS LABORATORY
WATERTOWN, MA 02172

COMMANDER
US ARMY ARMAMENT, MUNITIONS, & CHEMICAL
COMMAND
ATTN DRSMC-LCN-C(D), DR. F. TEPPER
ATTN DRSMC-ASF, R. ANDREJKOVICS
ATTN DRSMC-ASF, H. MacGRADY
ATTN DRSMC-LCN-C, G. R. TAYLOR
ATTN DRSMC-LCN-C, G. DEMITRACK
ATTN DRSMC-LCN-M, V. GENTILE
ATTN DRSMC-LCN-M, L. HOROWITZ
ATTN DRSMC-LCN-T, S. ISRAELS
ATTN DRSMC-LCN-T, R. NITSCHKE
ATTN DRSMC-SC(D), L. GHAZI
ATTN DRSMC-LCN-T, A. G. NASH
ATTN DRSMC-QAR-E
ATTN DRSMC-QAR-R
DOVER, NJ 07801

OFFICE OF THE DEPUTY CHIEF OF STAFF FOR
RESEARCH, DEVELOPMENT, & ACQUISITION
ATTN DAMA-CSM, MUNITIONS DIV, E. LIPPE
WASHINGTON, DC 20310

COMMANDER
US ARMY ABERDEEN PROVING GROUND
ATTN STEAP-TL, TECH LIB
ATTN STEAP-MT-T, P. KERTIS
ABERDEEN PROVING GROUND, MD 21005

COMMANDER/DIRECTOR
US ARMY ARMAMENT, MUNITIONS, &
CHEMICAL COMMAND
CHEMICAL SYSTEMS LABORATORY
ATTN DRDAR-CLJ-L, TECHNICAL LIBRARY BR
ABERDEEN PROVING GROUND, MD 21010

COMMANDER
US ARMY ARMAMENT, MUNITIONS, &
CHEMICAL COMMAND
ATTN DRSMC-LEP-L, TECHNICAL LIBRARY
ATTN DRSMC-ASF, FUZE & MUNITIONS
SUPPORT DIV

US ARMY ARMAMENT, MUNITIONS, &
CHEMICAL COMMAND (Cont'd)
ATTN DRSMC-LEW-F, J. FAHL
ROCK ISLAND, IL 62199

DIRECTOR
US ARMY BALLISTIC RESEARCH LABORATORY
ATTN DRSMC-BLT, TERMINAL BALLISTICS DIV,
D. SILVIA
ATTN DRSMC-TSB-S (STINFO)
ABERDEEN PROVING GROUND, MD 21005

COMMANDER
US ARMY MATERIEL COMMAND
ATTN DRUDE, DIR FOR DEVELOPMENT & ENG
5001 EISENHOWER AVE
ALEXANDRIA, VA 22333-0001

DIRECTOR
US ARMY MATERIEL SYSTEMS ANALYSIS
ACTIVITY
ATTN DRXSY-MP
ABERDEEN PROVING GROUND, MD 21005

COMMANDER
US ARMY MISSILE COMMAND
ATTN DRSMI-E, ENGINEERING
ATTN DRSMI-Q, PRODUCT ASSURANCE
ATTN DRSMI-RT, TEST & EVAL DIR
ATTN DRSMI-S, MATERIAL MANAGEMENT
REDSTONE ARSENAL, AL 35809

COMMANDER
US ARMY TEST & EVALUATION
COMMAND
ATTN DRSTE-CM-F, L. NEALLEY
ABERDEEN PROVING GROUND, MD 21005

COMMANDER
US ARMY TRAINING & DOCTRINE
COMMAND
ATTN ATCD-T, TEST & EVAL DIR
FT MONROE, VA 23651

COMMANDER
NAVAL SURFACE WEAPONS CENTER
ATTN DX-21, LIBRARY DIV
ATTN G-31, LARRY WICKS
DAHLGREN, VA 22448

COMMANDER
NAVAL SURFACE WEAPONS CENTER
ATTN E-43, TECHNICAL LIB
ATTN G-44
WHITE OAK, MD 20910

COMMANDER
ARMAMENT DEVELOPMENT & TEST CENTER
ATTN AD/YX, E. T. SMITH
EGLIN AFB, FL 32542

DISTRIBUTION (Cont'd)

ACTION MANUFACTURING CO
ATTN A. T. MATTIA
100 E ERIE AVE
PHILADELPHIA, PA 19134

ICI AMERICAS INC
PO BOX 819
ATTN JACK DAVIS (3 COPIES)
VALLEY FORGE, PA 19482

KDI PRECISION PRODUCTS
ATTN JERRY KRAMER
3975 McMANN RD
CINCINNATI, OH 45245

McDONNELL DOUGLAS ASTRONAUTICS CO
ATTN BOB HOCH
701 COLUMBIA BLVD
TITUSVILLE, FL 32780

PCB PIEZOTRONICS INC
ATTN RAYMOND LIMBURG
3425 WALDEN AVE
DEPEW, NY 14043

T. G. BRANDEN CORPORATION
ATTN BRIGITTE PARTINGTON
5565 SE INTERNATIONAL WAY
PORTLAND, OR 97222

US ARMY ELECTRONICS RESEARCH
& DEVELOPMENT COMMAND
ATTN COMMANDER, DRDEL-CG
ATTN TECHNICAL DIRECTOR, DRDEL-CT
ATTN PUBLIC AFFAIRS OFFICE, DRDEL-IN
ATTN J. GOON, DRDEL-PA (3 COPIES)

HARRY DIAMOND LABORATORIES
ATTN D/TSO/DIVISION DIRECTORS
ATTN RECORD COPY, 81200
ATTN HDL LIBRARY, 81100 (3 COPIES)
ATTN HDL LIBRARY, 81100 (WOODBIDGE)
ATTN TECHNICAL REPORTS, 81300
ATTN LEGAL OFFICE, 97000
ATTN ZABLUDOWSKI, B., 47400 (GIDEP)
ATTN CHIEF, 30000
ATTN INGERSOLL, P., 34000
ATTN BEARD, J., 34200
ATTN OVERMAN, D., 34200 (5 COPIES)
ATTN BRIGGMAN, D., 34300
ATTN DAVID, J., 34300
ATTN GOODMAN, R., 34400
ATTN COX, L., 00211
ATTN HOKE, J., 00211
ATTN POPE, G., 00211
ATTN CHIEF, 47400
ATTN CHIEF, 47500
ATTN CHIEF, 47700
ATTN CHIEF, 48500
ATTN CARPENTER, J., 34200 (8 COPIES)